

DIGITAL FOLDABLE STEAK THERMOMETER

USE INSTRUCTIONS

- Simple turn on by pressing the ON/OFF button on the back of the device.
 - Remove meat from cooking appliance. Insert thermometer probe into the meat making sure the probe is as close to the centre of the food as possible.
- Wait a minimum of 30 seconds before checking the temperature. This wait is necessary to allow time for the thermometer to stabilise and provide an accurate reading.
 - To obtain a precise temperature reading, it is important to ensure the probe's point is not resting on bone, gristle or the surface of the cookware.
 - Use the °C/°F button on the back of the device to swap between Celsius and Fahrenheit readout.
- This thermometer should only be used to take a temperature reading when the food is removed from the oven, barbecue or microwave. DO NOT leave thermometer in the meat whilst it is cooking.


BATTERY INSTALLATION:

Slide open the battery cover at the back of the thermometer, then insert 1 x LR44 (AG13) battery (included) into the battery compartment. Make sure "+" polarity of the battery is facing up. Then replace the battery cover.

Note: Before first use, slide open the battery cover at the back of the thermometer. Remove the plastic strip from the battery compartment. Then replace the battery cover.

CARE INSTRUCTIONS

Clean with a dry cloth. Do not immerse in water or wipe with damp cloth. Clean the probe with water and a mild detergent.



Avanti® is a registered trademark of
Sheldon and Hammond Pty. Ltd. A.B.N. 90 076 567 989
Product made in China to rigid specification
utilising high-grade materials. Packaging designed in Australia,
©Copyright Sheldon and Hammond Pty. Ltd. 2015.
Product Code 12933

www.avantihomewares.com